



# Folding instruction

## For the cover


1. Place the cardboard form on a flat surface and "exercise" the creases by bending them slightly back and forth.




2. Place the side walls of the box up and fold in the inner flaps. \* Start folding from the walls with the flaps closer to the plane of the cover.




3. Fold back the small flaps of the remaining two walls and the narrow age to the opposite side and fold these walls, enclosing the flaps described in step 2. \* Make sure to fold both creases of these walls.




4. Fold the narrow edge to the opposite side and fold the remaining walls, enclosing the flaps described in step 3. \* Also, make sure to fold both creases of these walls.



5. \* The narrow edges must "meet" at the corners and lock the cover walls to prevent them from unfolding.



6. Check for the kitty cat on the bottom of the box while you have been folding the cover.



7. If the cat is not lurking inside the box, fill it with your items and put on the cover.

